




replacement filter

INSTRUCTIONS FOR USE

For use with the closer to nature perfect prep machine

The filter cartridge has been sterilised and is certified as food grade.

- 

1 A red change filter warning light will illuminate when the filter needs replacing soon. If this light flashes, the filter must be changed immediately.
- 

2 Press the cleaning mode button for 2 seconds to empty the tank (ensure a suitably sized receptacle is under the dispenser outlet to collect the water). Then press the filter volume reset button for 2 seconds to clear the memory.
- 

3 Remove the old filter from the hopper and discard. Replace the hopper (without filter).
- 4 Handling the filter cartridge by the top only, remove the filter cartridge from packaging, remove sticker from the top of the filter, fill a bowl with potable (drinking) water, fully submerge the cartridge in the water and gently agitate it until the bubbles cease.
- 

5 Handling the filter by the top ring only insert the new filter into the clear plastic hopper of your perfect prep machine and place it back into the water tank of the appliance.
- 

6 Place a container under the appliance dispenser outlet (minimum 1 litre).
- 

7 Fill the hopper with cold tap water.
- 8 Wait for the tank level warning light to go out.
- 9 Press the on/off switch.
- 10 The appliance will dispense a small quantity of hot water.
- 11 Press the on/off switch again to finish the cycle.
- 12 Discard the dispensed water.
- 13 Your system is now ready to use.

filter care

The filter in this pack has been sterilised and is certified as food grade – please do not open until needed.

Always ensure good hygiene by washing your hands and work surfaces before handling the water filter.

Water is a foodstuff, please consume filtered water within 1-2 days.

A red warning light on your perfect prep machine will indicate when the filter needs to be replaced; please change the filter as soon as this is indicated for your child's safety and health.

Dispose of your filter in general household waste.

This product is intended to filter potable (drinking) water only. Do not put water of unknown quality into this product.

tommeetippee.com

*Based on the consumer preparing 6x 9oz feeds per day